

# Modified schematic for the ZX40

TO CANOPY THROUGH TUBE ASSEMBLY

**STEP 4**  
Connect the loose end of long harness to white/blue side of capacitors as shown.

**STEP 3**  
Replace entire connector.

**STEP 7**  
Move one black (double) wire from C1 to C3.

**STEP 5**  
Connect one end of jumper harness as shown.

**STEP 6**  
REMOVE THESE TWO WHITE WIRES FROM PINS 5 & 6 AND CONTACTOR, THEN DISCARD.

**STEP 6**  
Connect free end of harness to contactor.

