



## Procedure for Installation of the Canopy Trim Bracket

DISCONNECT POWER BEFORE STARTING THIS OR ANY SERVICE PROCEDURE REQUIRING THE REMOVAL OF PROTECTIVE COVERS.

If your original canopy stand arm looks like either of the two illustrated at right you will need to install the enclosed trim brackets with your new canopy stand arm. The trim brackets that come with this kit are attached to the sunbed's internal support rails as shown below.

After removing the canopy cover and damaged canopy stand arm attach the trim brackets as shown below. You may need to relocate some wiring harnesses in order to position the brackets properly. Simply unscrew the plastic wire clamp from the frame, move it to an acceptable location and screw down again. Reassemble the sunbed.

