

ATTENTION!

To avoid scratching the pedestal...

Before installing the modules onto the pedestal (see page 7 in your manual) you must install the two metal shims included in this hardware kit under the hinge brackets of the booth.

The photos below illustrate where to install the shims. Insert a shim under the hinge bracket under the left and right modules to lift the front of the booth. Use two shim washers to fill the gap under the bolt hole on each side as shown.

If you assemble the booth before reading this instruction sheet, simply loosen the bolts holding the left and right modules to the pedestal and insert the shims and shim washers where noted.

