

ADI-COM TIMER

Installation Instructions

1. Turn off power. (Unplug the bed or turn off the breaker in your breaker box.)
2. Remove the two Phillip screws holding the timer bezel to the canopy.
3. Remove the wire harness(s) form the board.
4. Reattach the wire harness(s) to the new timer kit
5. Reinstall the two screws into the bezel and screw into the canopy.
6. Turn on power and enjoy your tanning experience.

