

e3 Keypad Replacement Instructions

1. Remove handle cap by inserting a small flathead screwdriver into the rear of the handle slightly to separate the cap from the handle.
2. Unplug the keypad ribbon cable from the display PCB. The ribbon simply pulls out of the connector on the display PCB.
3. Insert the new keypad ribbon cable into the display PCB connector.
4. Press the cap onto the handle by putting the display end (top) on first. Snap it into place making sure the ribbon cable is not blocking the display.
5. Press the bottom of the cap into place.

Step 1



Step 3



Step 4

