


Wireless Module Quick Installation Guide


The T-Max® wireless module is designed for quick, easy setup. It allows a salon owner to add new equipment or a new T-Max® remote timer system without the hassle of hiring electricians or running wires through walls from room to room. It also isolates each bed timer electrically to avoid problems due to voltage spikes. Follow the instructions included in your tanning bed user manual and the T-Max® remote timer system manual, keeping in mind the following tips...

- DO** - mount the wireless module on the wall.
- DO** - mount the wireless module vertically with the RJ-11 jack at the bottom.
- DO** - mount the wireless module above the highest point the tanning unit will reach (canopy open).
- DO** - check that the tanning bed canopy or booth doors do not block the wireless unit.
- DO** - always use the RJ-11 cable supplied with the wireless module. If a longer one is needed, contact your place of purchase.

- DON'T** - mount the wireless module to the tanning unit.
- DON'T** - mount the wireless unit behind the tanning bed or booth where you cannot see it.
- DON'T** - mount the wireless unit near or behind any large metal objects, such as vending machines, metal decorations or plate glass mirrors. Also avoid metal wiring conduit and metal wall studs.
- DON'T** - cut the RJ-11 cable. If it is too long, simply roll up the excess.
- DON'T** - use standard phone cables.



**Signal can not pass through metal.
Do not place behind tanning beds.**



**While wireless modules can transmit through walls,
for best results make sure they can “see” each other.**