


VELOCITY AUDIO CABLES

Installation Instructions

1. 3.5mm to 3.5mm MP3 player to Tanning bed.
2. 2.5mm to 3.5mm Cell Phone type I to Tanning bed.
3. 2.5mm to 3.5mm Cell Phone type II to Tanning bed.




REV A
28163-01

VELOCITY AUDIO CABLES

Installation Instructions

4. Place the 90 degree bend plug into the associated audio device's jack.
5. Place the other end of the cable into the tanning bed's associated jack.
6. Pull the associated audio device away from the tanning bed until the desired length is made between the tanning bed and the associated audio device. The maximum distance is 48 inches.
7. If the associated audio device is small enough, place the associated audio device into the cubby hole during the tanning session or in a location desired by the customer so that the device is in a safe location.



VELOCITY AUDIO CABLES

Installation Instructions

8. Cell phone type I is cell phones that are mono, meaning when you plug in a pair of stereo headphones you only hear the audio in one ear. If this is the case, use number 2.
9. Cell phone type II is cell phones that are stereo, meaning when you plug in a pair of stereo headphones you hear the audio in both ears. If this is the case, use number 3.
10. Any other audio device such as MP3 players, Walkmans, or CD player or the like can use the number 1.

