


# Lamp Removal Tool

Grasp a lamp and twist a quarter turn. The lamp holder should click when you've turned far enough.

Pull the lamp from the lamp holders.

To reinstall a lamp, insert one end as usual, push toward the lamp holder to compress the spring action and then insert the other end. Use the tool to twist the lamp one quarter turn until it clicks.




30379-01A

# Lamp Removal Tool

Grasp a lamp and twist a quarter turn. The lamp holder should click when you've turned far enough.

Pull the lamp from the lamp holders.

To reinstall a lamp, insert one end as usual, push toward the lamp holder to compress the spring action and then insert the other end. Use the tool to twist the lamp one quarter turn until it clicks.



30379-01A