



Subject: CHANGING VELOCITY COOL DOWN TIME **Number:** SRV0003

Applicability: VELOCITY 918HP **Date:** 7/14/04

Symptoms: COOL DOWN TIME IS TOO LONG FOR SALON BUSINESS

Explanation: THIS IS FOR UNITS THAT ARE ALREADY IN THE FIELD AND THE SALON OWNER WANTS TO SHORTEN THE COOL DOWN TIME.

WARNING: THE MANUFACTURER RECOMMENDS A 10-MINUTE COOL DOWN TIME TO PROPERLY COOL THE SAFETY FILTER GLASS. COOL DOWN TIMES LESS THAN 7 MINUTES HAVE NOT BEEN TESTED. SETTING THE COOL DOWN TIME TO LESS THAN 7 MINUTES IS AT THE OWNER'S OWN RISK AND MAY VOID THE WARRANTY.

Solution: PROCEDURE FOR CHANGING THE COOL DOWN TIME IS AS FOLLOWS:

1. WITH THE POWER ON PRESS AND HOLD THE **STOP BUTTON** FOR ABOUT 20 SECONDS.
2. YOU WILL SEE IN THE DISPLAY THE WORDS "PROGRAM MACHINE".
3. RELEASE THE **STOP BUTTON** AND THE DISPLAY WILL SWITCH TO "LANGUAGE".
4. PRESS THE **STOP BUTTON** 5 TIMES. THE DISPLAY WILL READ "MACHINE COOLING – 10 MINUTES".

NOTICE: This document and the information disclosed herein are proprietary data of **ETS, Inc.** Neither this document nor the information contained herein shall be used, reproduced, or disclosed to others without the written authorization of **ETS, Inc.** except to the extent required for installation or maintenance of the recipient's equipment.

CAUTION: **ETS, Inc. Service Bulletins** are intended for use by experienced service technicians. They are written to inform those technicians of conditions that may occur in some equipment, or to provide information that could assist in the proper servicing of the equipment. If a condition is described, **DO NOT** assume that this service bulletin must be applied to your equipment, or that your equipment will develop that condition. Always consult your **ETS, Inc. Technical Service Representative** before performing any modifications to your equipment. When electrical service is needed, we recommend hiring a professional electrician.

5. USE THE +/- BUTTONS TO CHANGE THE TIME.

6. PRESS AND HOLD THE **TIME BUTTON** UNTIL THE DISPLAY READS "RECORDING PARAMETERS". LET OFF THE **TIME BUTTON** AND THE UNIT IS READY TO RUN.