


22958, REV A
16 LAMP TRAY, BENCH SIDE
WIRING DIAGRAM




B_BAL = BALLAST FOR BENCH

PIN #	P3 FUNCTIONS
1	LAMP RETURN 1
2	GROUND
3	LAMP RETURN 2
4	FAN RETURN
5	BODY FAN CONTROL
6	FAN FEED
7	LAMP RETURN 3
8	BODY FAN FEED
9	LAMP RETURN 4

WARNING: ALTERING THE DESIGN, TIMER SYSTEM, OR WIRING FROM THAT SHOWN HEREIN WILL VOID THE WARRANTY, AND MAY RESULT IN A VIOLATION OF FEDERAL LAW.

FRONT OF TRAY



20 LAMP TRAY, CANOPY SIDE WIRING DIAGRAM

C_BAL = BALLAST FOR CANOPY

PIN #	P2 FUNCTIONS
1	L1
2	SENSOR 1
3	L1
4	GROUND
5	SENSOR 2
6	NOT USED
7	BODY FAN CONTROL
8	FAN FEED
9	LAMP RETURN 1
10	LAMP RETURN 2
11	NOT USED
12	LAMP RETURN 3
13	LID ALARM
14	FAN CONTROL
15	LAMP RETURN 5
16	NOT USED
17	FAN RTN
18	NOT USED
19	SENSOR 2
20	LAMP RETURN 4
21	L2
22	CONTACTOR CONTROL
23	L2
24	SENSOR 1

FRONT OF TRAY