




Addendum to the User Manual for the F-model SunStar® ZX40 and ZX44



This instruction sheet is an addendum to your User Manual. After assembling the sunbed, but BEFORE POWER IS APPLIED, refer to this instruction sheet.

Modified schematic wiring diagrams are included with this instruction sheet to supplement the schematics found in the schematic packet in the bench box. Steps indicated on diagrams have already been performed and outline wiring enhancements.

Step 1 In the head end ballast tray, along with the colored cable assemblies, you will find the end of a two conductor cable (A) with spade connectors. Attached in the front of the tray are three cylinder shaped capacitors (C1, C2, C3) with eight terminals each. You will notice one side of the capacitor contains black and red wires while the other side contains white and blue. Connect the cable to two open terminals on the white/blue side of the capacitors. Make sure the connection is secure.

Step 2 In the foot end ballast tray is a shorter cable (B), like the long one coming from the canopy. Again, attach this cable to two open terminals on the white/blue side of the capacitors.

